




Elevation Window Control System

Network Adaptor Installation Instructions

INTERLOCK™
ASSA ABLOY

		Items Supplied	Tools Required
		<ul style="list-style-type: none"> ● Network Adaptor ● 6 Pin Cable ● Terminal Resistor Blocks (x2) ● Serial Number Label 	<ul style="list-style-type: none"> ● Hobby Knife ● Small Screwdriver ● Long Nose Pliers ● Wire Strippers

1 Important: Network Adaptor must be installed internally, e.g. in a wall or roof cavity



Dip Switches
Ensure that dip switches are all in the down or off position as shown. This is the default position.

