

lockset on rebated french doors

Drill

тоога ведиівер

Remove while away for added security in an emergency Leave Securiturn $^{\text{\tiny{TM}}}$ in deadbolt while at home for safe exit

Two Yale Rebate Kits (MC307) are required for installing ADDITIONAL Safety googles Chisel Hammer Phillips Screwdriver 25mm drill bit 16mm drill bit 3mm drill bit 54mm hole saw

components parts for individual inside pack See instructions entrance set 1 x Single cylinder

Securiturn[™] deadbolt with 1 x Double cylinder

SECURITURN™

СОИТЕИТЅ

PROFESSIONAL SERIES

FRONT & BACK DOORS COMBO LOCKSET