MC17FB (Florentine Bronze) MC17PB (Polished Brass) MC17SC (Satin Chrome)



RIM CYLINDER

REPLACEMENT RIM CYLINDER PROFESSIONAL SERIES

ENTRANCE

HIGH SECURITY

Suitable for timber



Suitable for hinged door



Easy install



Instructions included





RIM CYLINDER FOR DOORS

PROFESSIONAL SERIES

CONTENTS

- 1 x Anchor Plate 2 x Nails
- 2 x Retaining Screws
- 2 x Keys
- 1 x Cylinder
- 1 x Rose

TOOLS REQUIRED



Pozi screwdriver

Saw

1.Remove old cylinder

FITTING INSTRUCTIONS

Remove existing cylinder by unscrewing the fixings of the main lockset body and removing the lock body from door.

2.Remove old cylinder

Unscrew the two screws that retain the cylinder in the door and remove cylinder. Check that the tailpiece on the Yale cylinder is the same length as the old one. Note: Cut it to size using a hacksaw if it is longer.

3.Fit new cylinder

Place the Rim Cylinder in the existing cylinder hole and with anchor plate in position screw in the two retaining screws. Refit the main lockset body and test with key for correct operation of the Rim Cylinder and lockset.





The world's favourite lock www.yalelock.co.nz ASSA ABLOY New Zealand 6 Armstrong Road, Albany, Auckland 0632, New Zealand

Quality, ISO 9001 Environmental, ISO 14001

For customer feedback: nzsales@assaabloy.com



An ASSA ABLOY Group brand

