MC10





PROFESSIONAL SERIES

# **INCREASED SECURITY**

## Suitable for timber



Suitable for hinged door



Easy



Instructions included





# **HINGEBOLT**

PROFESSIONAL SERIES

### TOOLS REQUIRED

3mm drill bit

16mm drill bit

🥱 Drill

Pozi screwdriver

> Hammer

Safety goggles

## CONTENTS

2 x Bolts

2 x Plates

8 x 6g x25mm countersunk screws

### **FEATURES**

Provides increased security on timber doors

# Fixing Instructions:

#### Fitting bolts

- Select position on door for the two bolts 100mm below top hinge and 100mm above bottom hinge
- In centre of door edge drill 9.5mm diameter holes to a depth of 36mm
- Tap the two bolts in place (smaller diameter end first), gently close the door to allow the heads of the bolts to mark centre position for plates on the frame

# 2 Fitting plates

- On the frame, in the positions marked by the bolt, drill two 16mm diameter holes
  Locate the plates over the holes and drill 3mm diameter
  - Locate the plates over the holes and drill 3mm diamete fixing pilot holes 25mm in depth
- Screw the plates in position using 6g x 25mm screws

Note: If required, plate can be rebated flush into frame.







The world's favourite lock www.yalelock.co.nz

ASSA ABLOY New Zealand 6 Armstrong Road, Albany, Auckland 0632, New Zealand

Quality, ISO 9001 Environmental, ISO 14001

For customer feedback: nzsales@assaabloy.com





ASSA ABLOY