fold line

fold line

fold line

fold line

Yale Securiturn™ The Removable Turnknob

19



Securiturn[™] The Removable Turnknob

Securiturn[™] - Provides security with safety by providing immediate exit when installed in inside cylinder. Provides security when premises unoccupied as Securiturn[™] can be removed by inserting the release key and withdrawing Securiturn[™].

Note: Store in a safe place when not in use.

Preparing Securiturn[™]

Your local locksmith will prepare the Securiturn™ key to your current key cuts. Securiturn can then be used on your inside lock cylinder fitted with a standard LW4 keyway.



Locksmith Notes: Prepare vertical trap cut by filing back the leading face of selected pin cut to allow pin to drop to bottom of cut.



Use number 2, 3, 4 or 5 key cut with a number 3-pin depth or greater.

Note: On 6-pin key do not use last pin cut as the trap position.



cylinder.

Secure

Securiturn[™].

Use release key to remove

Securiturn[™] Applications:

Securiturn™ can only be used to add safety with security to the types of lock cylinders shown below, using the common LW4 Australasian keyway.



Oval Cylinder Deadbolt Cylinder Euro "E" Cylinder See note: (1B to 3B)

Safe Plug

In commercial premises and in some domestic situations, a permanent Turnknob may be required. The red Safe Plug supplied with every Securiturn™ can be inserted (with Securiturn™ disassembled) into the release key slot (from the inside). With Safe Plug in place Securiturn™ cannot be removed.



Provides security with safety for double cylinder locks fitted with standard LW4 cylinders.



ASSA ABLOY New Zealand Limited 6 Armstrong Road, Albany Auckland 0632, New Zealand www.yalelock.co.nz For customer feedback: info.nz@assabloy.com

ASSA ABLOY

An ASSA ABLOY Group brand



