



Door and latch preparation template



Door preparation and latch installation (steps 1-9)



Passage and Privacy set installation (steps 10 - 21)

10 Privacy button	11	12	13	14
PRIVACY SET (displayed) Parts and assembly DO NOT REMOVE SCREWS	Position lever assembly (side with screws) so that it operates downward to retract the latch bolt.	Align spindle into the square opening in latch, screws pass through screw holes.	Locate opposite lever (side without screws), align screw heads through large screw holes in furniture.	Rotate rose furniture to align screws with countersunk holes.
15	16 Removal tab	17 Emergency access hole	18	19
Lightly tighten fixing screws. Check levers are horizontal and in line with the latch. Then firmly tighten fixing screws.	Pass trim over lever. Push trim to secure. Position removal tab to the bottom.	PRIVACY SET ONLY On the exterior side of door align emergency access holes on trim and furniture.	PRIVACY SET ONLY Screw in the privacy button on the interior side of door through hole in trim.	PRIVACY SET ONLY Depressing the privacy button will lock the (exterior) outside lever.
20	21	* FOR OUTWARD OPENING DOORS REFER TO STEP 7 & 8.		
PRIVACY SET ONLY Rotate (interior) inside lever to release privacy lock.	PRIVACY SET ONLY Insert and push pointed tool to gain access from the (exterior) outside when the privacy button is engaged.			

Strike preparation and installation (steps 22 - 27)

22	23	24 Door stop	25	26
Partially close door. Mark centre of latch bolt. Mark horizontal line along the inside face of the door jamb.	Measure the door thickness and halve it.	From the door stop along the horizontal line, measure and mark a vertical line at half the door thickness.	At this point drill 25mm hole, 13mm deep into the door jamb.	Align strike plate centrally and vertically over this hole. Mark around plate. Chisel out jamb to allow strike plate to sit flush.
27				
Drill 2x 2mm pilot holes and affix screws provided.				