

P/No. YSL-5121 04/18

P/No. YSL-5121 04/18


P/No. YSL-5121 04/18

- P/No. YSL-5121 04/18

P/No. YSL-5121 04/18


- P/No. YSL-5121 04/18

P/No. YSL-5121 04/18




- P/No. YSL-5121 04/18

P/No. YSL-5121 04/18





- P/No. YSL-5121 04/18

P/No. YSL-5121 04/18




- P/No. YSL-5121 04/18

P/No. YSL-5121 04/18



P/No. YSL-5121 04/18





5

DOOR PREPARATION

- Establish height that lockset will be mounted on door and mark centreline of door thickness on door edge.
- Place Mortise Template on door and align centreline on template with centreline on door.
- Mark and drill mortise to suit mortise lock depth (90mm).

7

LOCKS AND CYLINDERS

- Place lock in mortise and insert cylinder.
- Secure cylinder with retainer pin, ensuring pin is flush with front plate.
- Install Cover plate and secure with 2 M4 screws provided to lock body.

9

LOCKS WITH SPINDLES

- Spindles are supplied with the furniture.
- Insert spindle(s) into lock, as required.
- Assemble furniture as required. Ensure furniture is not over-tightened.

6

DOOR PREPARATION

- Ease out mortise cavity where necessary. Clean out mortise before inserting lock.
- Insert lock in mortise with Cover Plate on and scribe around Cover Plate for size of recess, ensuring that no foreign matter finds it way into the lock mechanism.
- Remove lock from mortise and chisel recess 4mm deep to receive both front and cover plate. Cover plate must be flush with edge of door.
- Ensure lock is removed from mortise cavity. Fold template along backset fold line. Align EDGE A with bottom of cover plate recess. Establish holes required to suit lock function, mark hole centres accurately, drill and clean holes.
- Drill furniture holes as required.
- Fasten mortise lock into door using mounting screws provided.

8

LOCKS WITH TURNKNOBS

LATCHING OR LOCKING TURNKNOB

- Mark correct length of connecting bar as shown.
- For locking turnknob, mark the connecting bar at the edge of the screw on the mounting lock faceplate.
- Cut connecting bar to length, remembering to remove the burr.
- When lockset is in unlocked condition, turnknob to be vertical.

10

MOUNTING STRIKE

- Mark out door frame for strike.
- Use strike and strike box as templates and then mortise door frame for strike.
- Screw strike and strike box to the door frame with two screws supplied with
 - Timber frames - drill 2.5mm pilot holes and use 30mm long screws
 - Metal frames - drill 4mm pilot holes and use 12mm long screws
- To eliminate the rattle between the door and plate, bend the tab by small increments.